


**BULLARD
SOLAR**
One with the Sun

BOLITE

INSTALLATION TYPE:
BOLLARDS







sales@gordonbullard.com
www.bullardsolar.com
1 877-964-4646




991 South Gull Lake Dr.
Richland, MI 49083
USA



1. Take out the lamps and find the corresponding accessories.





2. Fix the anchor kit into the cement ground to adjust the level.



3. Fix the lamp on the anchor kit.


4. Lamp size drawing



sales@gordonbullard.com
www.bullardsolar.com
1 877-964-4646




991 South Gull Lake Dr.
Richland, MI 49083
USA




sales@gordonbullard.com
www.bullardsolar.com
1 877-964-4646




991 South Gull Lake Dr.
Richland, MI 49083
USA



1. Take out the lamps and find the corresponding accessories.




2. Fix the anchor kit into the cement ground to adjust the level.



3. Fix the lamp on the anchor kit.

4. Lamp size drawing



sales@gordonbullard.com
www.bullardsolar.com
1 877-964-4646



991 South Gull Lake Dr.
Richland, MI 49083
USA